RELEASE NOTES

June 2023


BASALTE STUDIO | CORE - V6.8.1

NEW UPDATE PROCEDURE

We have a non-critical update of your Core server ready which means that this update will not be automatically sent to your server. You have the possibility to manually upgrade and schedule the update via the pro.basalte.live portal.

Step 1 - schedule update in pro.basalte.live portal:

- 1. Go to pro.basalte.live.
- 2. Select the project that needs the update.
- 3. Select the Core server.
- 4. Press 'Schedule update'.




Step 2 - update Core server in Basalte app:

- 1. Go to the Basalte app.
- 2. Press '...' in the right corner > 'Settings' > 'About'.
- 3. Press 'Check updates'.
- 4. This Core server will now download the latest available release.
- 5. Once the download is finished, you can update the Core server.

Fast track

If you enable 'Fast track for updates', the Core server will update automatically as soon as a new release is available. This way, you are always first to discover our latest and greatest features!





Added louver modes in the KNX thermostat

The user can control the angle of the air blowing into the room.

Integration for iTach relay devices from Global Caché

Control devices in logic via a PoE contact closure relay. Works with the Global Caché IP2CC(-P) iTach.

Setpoint precision

Allow the user to change the setpoint in steps of 0.5° or 1° C.

FIXES AND IMPROVEMENTS

Improved Samsung TV control

The issue of losing sudden IP control, that occurred with certain Samsung TVs, is resolved.

- Improved communication in large Lutron QSX projects
- Added the option to manually import the configuration from a Lutron processor QS(X)
- KNX delays are configurable in Studio

The Core server adjusts the transmission speed of KNX telegrams based on the amount of traffic or data on the KNX bus. It is now possible to add additional read and write delays in Studio. Which might be necessary when working with slower KNX actors. But be careful, adding write delays can create a bad user experience.

- Improved ID assignment for Sentido RS485, Fibonacci RS485 and Auro RS485
- Fixed various Sonance issues

We fixed an issue with startup volume on Sonance DSP amplifier when controlled over over IP.

- Various DSP fixes and improvements
- Fixed an issue with importing IR codes in Studio

When manually adding longer hex codes in Studio, it is now possible to save them correctly.

KNOWN ISSUES

We are aware that there are instances of Studio crashes occurring when objects are being moved in the topology. Our team is actively addressing this issue and developing a solution. The fix will be incorporated in the upcoming Studio release.


BASALTE APP - V6.2.8

NEW FEATURES

Schedulers

Copying schedulers to another day is made more intuitive.

- 1. Select the copy icon on the schedule you wish to copy.
- 2. Press the paste icon on the day you wish to adjust.



FIXES AND IMPROVEMENTS

- Fixed audio alert modal not disappearing on Lena, Ellie and Lisa
- Fixed IP camera not showing its stream in list of cameras when trying a HTTPS connection